

INSTALLATION DETAILS

3053-D

IMPORTANT:
Pre-drill and screw
tub flange to studs.
Do Not force tub flange
to studs, this will cause
the tub door to leak.

